AUTOMATIC CLIMATE CONTROL

107.045/.048 INDEX	
ACC Grounds Distribution	339
ACC Power Distribution	339
Air Delivery (Electrical)	333
(Vacuum)	335
Component Location Table	341
Component Mode Table	340
Compressor Clutch Control	338
Pushbutton Control Assembly	301
Temperature Control	337


123.123/.133/.153/.1	93
INDEX	
ACC Grounds Distribution	308

ACC Grounds Distribution	308
ACC Power Distribution	308
Air Delivery (Electrical)	302
(Vacuum)	304
Component Location Table	310
Component Mode Table	309
Compressor Clutch Control	307
Pushbutton Control Assembly	301
Temperature Control	306

126.032/.033/.035/.037/ .039/.043/.044/.045/.120/ .125 INDEX

ACC Grounds Distribution	321
ACC Power Distribution	321
Air Delivery (Electrical)	314
(Vacuum)	316
Blower Control	315/2
Component Location Table	323
Component Mode Table	322
Compressor Clutch Control	
$(126.032/.033/.037/.043/.044) \dots$	318
(126.035/.039/.045)	318/1
(126.120)	319
(126.125)	319/3
Pushbutton Control Assembly	301
Temperature Control	320

PUSH BUTTON CONTROL ASSEMBLY




FUNCTION CONTROL SWITCHES

REVISIONS:


(For Component Locations See Page 310)

300 D/CD/TD



AIR DELIVERY (VACUUM)


(For Component Locations See Page 310)



REVISIONS:


2/83

123.133/.153/.193




TEMPERATURE CONTROL

(For Component Locations See Page 310)




123.133/.153/.193



123.133/.153/.193

AUTOMATIC CLIMATE CONTROL (ACC) POWER AND GROUND DISTRIBUTION

(For Component Locations See Page 310)



REVISIONS

COMPONENT MODE TABLE 300 D/CD/TD

	MODES											
COMPONENTS	IGNITION	OFF O		TOTAL VENTILATION			NORMAL 🕡			ECONOMY EC		DEFROST
	OFF	(HEAT)	(COOL)	(HEAT)	(COOL)	(COOL at "MIN")	(HEAT)	(COOL)	(COOL at "MIN")	(HEAT)	(NO HEAT)	
HEATER WATER VALVE	OPEN	CLOSED	CLOSED	CYCLING	CLOSED	CLOSED	CYCLING	CLOSED	CLOSED	CYCLING	CLOSED	OPEN
AUXILIARY WATER PUMP	OFF	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	ON
COMPRESSOR CLUTCH	OFF	OFF	OFF	ON	ON	ON	ON	ON	ON	OFF	OFF	ON
CENTER FLAP (Switchover valve code 3)	CLOSED	CLOSED	OPEN	CLOSED	OPEN	OPEN	CLOSED	OPEN	OPEN	CLOSED	OPEN	CLOSED
FOOTWELL FLAPS (Switchover valve code 2)	CLOSED	CLOSED	CLOSED	OPEN	OPEN	OPEN	OPEN	CLOSED	CLOSED	OPEN	CLOSED	CLOSED
DEFROST FLAPS (Switchover valve code 1)	FULLY OPEN	ALMOST CLOSED	FULLY CLOSED	FULLY OPEN	FULLY OPEN	FULLY OPEN	ALMOST CLOSED	FULLY CLOSED	FULLY CLOSED	ALMOST CLOSED	FULLY CLOSED	FULLY OPEN
MAIN AIR FLAP (Switchover valve code 5)	CLOSED	CLOSED	CLOSED	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
FRESH/IN-CAR AIR FLAP (Switchover valve code 4)	CLOSED	CLOSED	OPEN	CLOSED	OPEN	OPEN	CLOSED	OPEN	OPEN	CLOSED	CLOSED	CLOSED

COMPONENT LOCATIONS 300 D/CD/TD

AUTOMATIC CLIMATE CONTROL

Aspirator	Behind blower housing	
Auxiliary Water Pump	Behind RH headlights	312-2
Blower Motor	Under RH side of dash	
Blower Resistors	Forward of RH front wheel well	312-2
Center Flap Switchover		
Valve (Code 3)	In switchover valve group, third from left	312-3
Center Flap Vacuum Element	Top center of plenum	311-5
Cold Engine Lockout Switch	(300 D/CD/TD) RH side of engine	310-2
Compressor Low Pressure		
Cut-Out Switch	Top of receiver-drier	312-2
Compressor Relay	Top of LH front wheel well in relay box	310-1
Defrost Flaps Switchover		
	In switchover valve group, far left	312-3
Defrost Flaps Vacuum		
Element	On LH side of plenum	312-5
Electronic Unit For		
Blower Speed Control	Above passenger's footwell	312-1
Electronic Unit For		
Temperature Control	Above passenger's footwell	312-1
Evaporator Temperature		
Regulator	Above passenger's footwell	312-€
Footwell Flaps Switchover		
Valve (Code 2)	In switchover valve group, second from left	312-3
Footwell Flaps Vacuum		
Element	On LH side of plenum	312-5
Fresh/Recirculated Air Flap		
Switchover Valve (Code 4)	In switchover valve group, fourth from left	312-3
Fresh/Recirculated Air		
Flap Vacuum Element	On plenum, behind RH side of glove box	
	Behind console	312-3
	RH rear of engine compartment	311-1
•	In header above rear view mirror	
Main Air Flap		
- I - I - I - I - I - I - I - I - I - I	In switchover valve group, far right	312-3
Main Air Flap		
	On plenum, behind LH side of glove box	312-4
	Behind console	312-3
	RH side of engine	311-3
G102	Behind instrument cluster	311-2




Figure 1 - LH Front Wheel Well




Figure 2 - Front RH Side of Engine

REVISIONS:

COMPONENT LOCATIONS




Figure 1 - Engine Compartment




Figure 2 - Behind Instrument Cluster




Figure 3 - RH Front Wheel Well




Figure 4 - Heater Air Sensor

5293




Figure 5 - Above Center Of Plenum

COMPONENT LOCATIONS




Figure 1 - Behind Glove Box




Figure 2 - RH Wheel Well




Figure 3 - In Console, Behind Pushbutton Control Assembly



Figure 4 - Behind Glove Box




Figure 5 - On LH Side of Plenum




Figure 6 - Behind Glove Box

REVISIONS: